


# Mazzer Doser Grinders




1553 NW Ballard Way  
Seattle WA 98107  
Tel: 206.706.9104  
Fax: 206.706.9106  
[www.lamarzoccousa.com](http://www.lamarzoccousa.com)

# Mini




| Position | Description                                    | Part Number    |
|----------|------------------------------------------------|----------------|
| 1        | Mini Hopper (no lid)                           | M28350001      |
| 2        | Mini Hopper Lid                                | M28054009      |
| 3        | Hopper Locking Slide                           | M28326010/VT   |
| 5        | Coffee Grinding Adj. Disk , SJ / Mini E / Kony | M28157         |
| 7        | Grinding Adjustment Disk Handle                | M28360012      |
| 8        | Upper Burr Holder, Mini                        | M28360011/MINI |
| 9        | Mini Grinding Burrs 182-D                      | M28217003      |
| 10       | Lower Grinding Burr Holder , Mini              | M28253/MINI    |
| 12       | Bearing, 6202                                  | M28057         |
| 13       | Grinding Adjustment Spring                     | M28233         |
| 15       | Gasket Aer-Stop                                | M28400004      |
| 16       | Mini ETL Manual Doser                          | M28100/MINI    |
| 17       | Doser fixing Support                           | M28258007      |
| 18       | Major Burrs                                    | M28215         |
| 21       | Complete Two Pole Timer Switch                 | M28162         |
| 23       | Timer Switch Knob                              | M28162/K       |
| 24       | Two Pole Rotative Switch, On/Off               | M28161         |
| 26       | Knob for M28161 & M28166 Switches              | M28166/K       |
| 27       | Green Light Switch                             | M28163/MINI    |
| 28       | Fork, (Standard Doser)                         | M28122         |
| 29       | Pilot Light, 110V UL, Red                      | M28258006      |
| 30       | Drip Tray (Metal, Square)                      | TRAY/MINI      |
| 35       | Capacitor 20 uF                                | M19051         |
| 37       | CONTACTOR 110V/60HZ 9 AMP (SMALL)              | M28341         |
| 39       | Terminal Blocks                                | M28903         |
| 40       | Under Terminal Blocks                          | M28904         |
| 41       | Ground Plate                                   | M28902         |
| 42       | Mazzer Foot                                    | M28258         |
| 42A      | SCREW TC 5X20 FOR BACK FOOT                    | M28258/SCL     |
| 42B      | SCREW, TC 5X12 6107 ZINC                       | M28258/SCS     |
| 43       | Mazzer Power Cable                             | M30022         |
| 46       | External Unipotential Clamp, Plate             | M28905         |
| 47       | Mazzer Grounds Tray Clip                       | M28259         |

# Mini Doser




| Position | Description                          | Part Number |
|----------|--------------------------------------|-------------|
| 1        | Mazzer Doser Lid                     | M28055      |
| 2        | Cylinder for Mini Doser              | M28051/MINI |
| 3        | DOSER ADJUSTMENT KNOB                | M28202      |
| 4        | Mini Upper Dosing Star               | M28300/MINI |
| 5        | Coffee Outlet Cover Plate            | M28323      |
| 6        | Mazzer Female Dosing Star            | M28301      |
| 7        | Mazzer Dosing System Pressing Spring | M28218      |
| 8        | Male Dosing Star                     | M28302      |
| 9        | Doser Washer D. 5 thick 0,4          | M28303      |
| 10       | Mazzer Complete Upper Micro switch   | M28240      |
| 11       | Coffee Outlet Cover Plate, MINI      | M28323/MINI |
| 14       | Tamper Press, Diameter 57.5mm        | M28251      |
| 16       | Corrugated Ring                      | M28002000   |
| 17       | Mazzer Doser Ratchet                 | M28066      |
| 18       | Mazzer Doser Adjustment Screw M8X70  | M28394      |
| 19       | Mazzer Complete Counter              | M28052      |
| 22       | Micro switch Star                    | M28299      |
| 23       | Lower Micro Switch                   | M28239      |
| 24       | Doser Bottom Plate Complete          | M28126      |
| 25       | Nose / Acciaio AISI 304              | M28249000   |
| 26       | Doser Return Lever                   | M28196      |
| 27       | Doser Lever Return Spring            | M28220      |
| 29       | Nose Spring                          | M28231      |

# Normale - Super Jolly




| Position | Description                                    | Part Number  |
|----------|------------------------------------------------|--------------|
| 1        | Mazzer Hopper Lid                              | M28053       |
| 2        | Mazzer Hopper with Collar (no lid)             | M28351       |
| 5        | Hopper Locking Slide                           | M28326010/VT |
| 6        | Coffee Grinding Adj. Disk , SJ / Mini E / Kony | M28157       |
| 8        | Upper Burr Holder, Super Jolly                 | M28360011    |
| 9        | Super Jolly Burrs                              | M28213       |
| 10       | Super Jolly/Mini 'E' Lower Burr Holder         | M28253       |
| 11       | Bearing, 6202                                  | M28057       |
| 12       | Grinding Adjustment Spring                     | M28233       |
| 17       | Gasket Aer-Stop                                | M28400004    |
| 18       | Mazzer 4M Back Plate. Mini, SJ, K, M, R        | M28535       |
| 19       | Fork, (Standard Doser)                         | M28122       |
| 20       | Pilot Light, 110V UL, Red                      | M28258006    |
| 22       | Complete Two Pole Timer Switch                 | M28162       |
| 25       | Timer Switch Knob                              | M28162/K     |
| 26       | Two Pole Rotative Switch, On/Off               | M28161       |
| 28       | Knob for M28161 & M28166 Switches              | M28166/K     |
| 29       | Mazzer Foot                                    | M28258       |
| 29A      | SCREW TC 5X20 FOR BACK FOOT                    | M28258/SCL   |
| 29B      | SCREW, TC 5X12 6107 ZINC                       | M28258/SCS   |
| 34       | Capacitor, 30 uF                               | M19056       |
| 35       | Terminal Blocks                                | M28903       |
| 36       | CONTACTOR 110V/60HZ 9 AMP (SMALL)              | M28341       |
| 38       | Small mazzer Drip Tray, M / SJ / K / R / KOLD  | TRAY/SM      |
| 39       | Grinding Adjustment Disk Handle                | M28360012    |
| 42       | Ground Plate                                   | M28902       |
| 43       | External Unipotential Clamp, Plate             | M28905       |
| 47       | Under Terminal Blocks                          | M28904       |
| 48       | Doser fixing Support                           | M28258007    |
| 50       | Mazzer Grounds Tray Clip                       | M28259       |
|          |                                                |              |

# Kony




| Position | Description                                    | Part Number |
|----------|------------------------------------------------|-------------|
| 1        | Mazzer Hopper Lid                              | M28053      |
| 3        | Kony Hopper, with Collar (no lid)              | M28351003   |
| 4        | Locking Hopper Slide                           | M28326010   |
| 6        | Grinding Adjustment Disk Handle                | M28360012   |
| 8        | Conical Grinding Burrs, 191C Kony              | M282191     |
| 9        | Coffee Grinding Adj. Disk , SJ / Mini E / Kony | M28157      |
| 10       | Upper Burr Holder, Kony                        | M28360030/K |
| 11       | Grinding Adjustment Spring                     | M28233      |
| 13       | Hopper Safety Switch                           | M28241      |
| 14       | Lower Burr Holder, Kony                        | M28253/K    |
| 15       | Bearing, 6202                                  | M28057      |
| 19       | UL Automatic Doser, M , R, K                   | M28099      |
| 20       | Gasket Aer-Stop                                | M28400004   |
| 21       | 3 x 3 x 30 Key                                 | M28254      |
| 26       | Doser fixing Support                           | M28258007   |
| 27       | Fork, (Standard Doser)                         | M28122      |
| 28       | Pilot Light, 110V UL, Red                      | M28258006   |
| 29       | Small mazzer Drip Tray, M / SJ / K / R / KOLD  | TRAY/SM     |
| 30       | Filter /Screen for 60 X 60 Fan                 | M28530/M    |
| 33       | Two Pole Rotative Switch+ Aux ON/OFF/START     | M28166      |
| 35       | Knob for M28161 & M28166 Switches              | M28166/K    |
| 41       | 4 X 4 X 14 Key                                 | M28255      |
| 42       | Load Resistor 68 Kilo-Ohm 2 Watt               | M28710      |
| 43       | Contacto 110V/60 HZ 18 AMP (Large)             | M28341/NT   |
| 44       | Relay, Kony                                    | M28347      |
| 46       | Capacitor, 30 uF                               | M19056      |
| 47       | Capacitor 40 uF                                | M19057      |
| 49       | Mazzer Foot                                    | M28258      |
| 49A      | SCREW TC 5X20 FOR BACK FOOT                    | M28258/SCL  |
| 49B      | SCREW, TC 5X12 6107 ZINC                       | M28258/SCS  |
| 50       | External Unipotential Clamp, Plate             | M28905      |
| 52       | Ground Plate                                   | M28902      |
| 54       | Under Terminal Blocks                          | M28904      |
| 55       | Terminal Blocks                                | M28903      |
| 58       | Mazzer Power Cable                             | M30022      |
| 62       | Mazzer Grounds Tray Clip                       | M28259      |

# Major




| Position | Description                                   | Part Number |
|----------|-----------------------------------------------|-------------|
| 1        | Mazzer Hopper Lid                             | M28053      |
| 2        | Robur/Major Hopper, with Collar (no lid)      | M28351002   |
| 4        | Locking Hopper Slide                          | M28326010   |
| 5        | Grinding Adjustment Disk Handle               | M28360012   |
| 6        | Coffee Grinding Adjustment Disk, Major/Robur  | M28158      |
| 8        | Major Upper Burr Holder                       | M28360030   |
| 9        | Major Burrs                                   | M28215      |
| 10       | Major Lower Burr Holder                       | M28253/M    |
| 12       | Bearing, 6204                                 | M28063      |
| 13       | Hopper Safety Switch                          | M28241      |
| 14       | Grinding Adjustment Spring                    | M28233      |
| 16       | Gasket Aer-Stop                               | M28400004   |
| 17       | UL Automatic Doser, M , R, K                  | M28099      |
| 19       | Doser fixing Support                          | M28258007   |
| 20       | Mazzer 4M Back Plate. Mini, SJ, K, M, R       | M28535      |
| 23       | Complete Two Pole Timer Switch                | M28162      |
| 25       | Timer Switch Knob                             | M28162/K    |
| 26       | Two Pole Rotative Switch, On/Off              | M28161      |
| 28       | Knob for M28161 & M28166 Switches             | M28166/K    |
| 29       | Fork, (Standard Doser)                        | M28122      |
| 30       | Pilot Light, 110V UL, Red                     | M28258006   |
| 31       | Small mazzer Drip Taya, M / SJ / K / R / KOLD | TRAY/SM     |
| 36       | Contacto 110V/60 HZ 18 AMP (Large)            | M28341/NT   |
| 38       | Capacitor 60 uF                               | M19058      |
| 41       | External Unipotential Clamp, Plate            | M28905      |
| 42       | Ground Plate                                  | M28902      |
| 43       | Mazzer Power Cable                            | M30022      |
| 45       | Load Resistor 68 Kilo-Ohm 2 Watt              | M28710      |
| 46       | Terminal Blocks                               | M28903      |
| 47       | Under Terminal Blocks                         | M28904      |
| 48       | Mazzer Foot                                   | M28258      |
| 48A      | SCREW TC 5X20 FOR BACK FOOT                   | M28258/SCL  |
| 48B      | SCREW, TC 5X12 6107 ZINC                      | M28258/SCS  |
| 49       | Mazzer Grounds Tray Clip                      | M28259      |

# Robur



| Position | Description                                   | Part Number |
|----------|-----------------------------------------------|-------------|
| 1        | Mazzer Hopper Lid                             | M28053      |
| 3        | Robur/Major Hopper, with Collar (no lid)      | M28351002   |
| 4        | Locking Hopper Slide                          | M28326010   |
| 5        | Hopper Safety Switch                          | M28241      |
| 7        | Mazzer 4M Back Plate. Mini, SJ, K, M, R       | M28535      |
| 10       | Two Pole Rotative Switch+ Aux ON/OFF/START    | M28166      |
| 12       | Knob for M28161 & M28166 Switches             | M28166/K    |
| 14       | Gasket Aer-Stop                               | M28400004   |
| 15       | UL Automatic Doser, M, R, K                   | M28099      |
| 16       | Doser fixing Support                          | M28258007   |
| 17       | Pilot Light, 110V UL, Red                     | M28258006   |
| 18       | Fork, (Standard Doser)                        | M28122      |
| 19       | Small mazzer Drip Tray, M / SJ / K / R / KOLD | TRAY/SM     |
| 21       | Adjustment Collar Bolt                        | M28360015   |
| 22       | Grinding Adjustment Disk Handle               | M28360012   |
| 23       | Coffee Grinding Adjustment Disk, Major/Robur  | M28158      |
| 25       | Upper Burr Holder, Robur                      | M28360030/R |
| 26       | Grinding Adjustment Spring                    | M28233      |
| 27       | Burrs, 186C, Robur / Kold                     | M282186     |
| 29       | Lock Nut for Grinding Adjustment Disk         | M28360019   |
| 30       | Lower Burr Holder, Robur/Kold                 | M28253/R    |
| 31       | O-Ring, NB70, Seal                            | M30009      |
| 32       | Bearing, 6202                                 | M28057      |
| 35       | 3 x 3 x 30 Key                                | M28254      |
| 41       | Bearing, 6204                                 | M28063      |
| 42       | Cooling Fan, Robur/Kold                       | M30019      |
| 43       | 4 X 4 X 14 Key                                | M28255      |
| 50       | Contactor 110V/60 HZ 18 AMP (Large)           | M28341/NT   |
| 51       | Cable Locking HSK-K PG11 Black                | M30020      |
| 53       | Ground Plate                                  | M28902      |
| 55       | Mazzer Power Cable                            | M30022      |
| 56       | External Unipotential Clamp, Plate            | M28905      |
| 58       | Mazzer Grounds Tray Clip                      | M28259      |
| 59       | Mazzer Foot, Robur/Kold                       | M28258/R    |
| 60       | Under Terminal Blocks                         | M28904      |
| 61       | Load Resistor 68 Kilo-Ohm 2 Watt              | M28710      |
| 62       | Terminal Blocks                               | M28903      |
| 63       | Capacitor 60 uF                               | M19058      |
| 65       | Capacitor 80 uF                               | M19060      |
| 66       | New Style, Relay for Robur / Kold             | M28346      |

# Doser



| Position | Description                               | Part Number |
|----------|-------------------------------------------|-------------|
| 1        | Mazzer Doser Lid                          | M28055      |
| 2        | Cylinder Window, Inside Doser SJ, K, M, R | M28051      |
| 3        | DOSER ADJUSTMENT KNOB                     | M28202      |
| 4        | Upper Dosing Star, Supper Jolly, Kony     | M28300      |
| 4        | Upper Dosing Star, Major, Robur           | M28300/M    |
| 5        | Coffee Outlet Cover Plate                 | M28323      |
| 6        | Mazzer Female Dosing Star                 | M28301      |
| 7        | Mazzer Dosing System Pressing Spring      | M28218      |
| 8        | Male Dosing Star                          | M28302      |
| 9        | Doser Washer D. 5 thick 0,4               | M28303      |
| 10       | Mazzer Complete Upper Micro switch        | M28240      |
| 11       | Coffee Outlet Guard                       | M28250      |
| 13       | Tamper Press, Diameter 57.5mm             | M28251      |
| 15       | Mazzer Complete Counter                   | M28052      |
| 18       | Micro switch Star                         | M28299      |
| 19       | Lower Micro Switch                        | M28239      |
| 20       | Corrugated Ring                           | M28002000   |
| 21       | Mazzer Doser Ratchet                      | M28066      |
| 22       | Mazzer Doser Adjustment Screw M8X70       | M28394      |
| 23       | Doser Bottom Plate Complete               | M28126      |
| 24       | Doser Lever Return Spring                 | M28220      |
| 25       | Nose Spring                               | M28231      |
| 26       | Nose / Acciaio AISI 304                   | M28249000   |
| 28       | Doser Return Lever                        | M28196      |