


KOLD ELECTRONIC GRINDER DOSER

EXPLODED VIEW





Position	Description	Part Number
1	Kold Hopper cover	M28054
2	Kold Hopper	M28351004
4	Kold Locking Hopper Slide	M28326011
5	Kold Hopper, Locking Pivot	M28360017
7	Hopper Safety Switch	M28241
8	Cap for TCE M6 Screw	M28901
11	Filter Screen, for 80 x 80 Fan	M28530/R
12	Frame for 80 x 80 Fan	M28520/R
13	Fan 80 x 80 Wired	M28510/R
15	Kold Knob Toothed Ring	M29001
16	Kold Knob Return Spring	M29002
17	Knob Mobile Support	M29003
18	Plastic Cap	M29004
19	Kold Grind Adjustment Knob	M29005
20	Knob Graduated Ring	M29006
21	Knob Axle	M29007
22	Knob Fix Support	M29008
23	Kold Single Phase Upper Grinding Blade Holder	M28360030/KOLD
25	Burrs, 186C, Robur / Kold	M282186
26	Lower Burr Holder, Robur/Kold	M28253/R
27	Grinding Adjustment Spring	M30001
28	Worm Screw Axle Support	M30002
29	Kold Worm Screw	M30003
30	Worm Screw Axle	M30004
31	Kold Helical Gear	M30005
32	Bearing 6002	M28057
33	Kold Ball Bearing Bushing	M30006
34	3 x 3 x 30 Key	M28254
35	Kold Grinding Shaft	M30007
36	4 x 4 x 22 Key	M28255/L
37	Driven Pulley shaft	M30008
38	Bearing 6204	M28063
39	O-Ring, NB70, Seal	M30009
41	Ball Bearing Holder Cap	M30010
42	Kold Driven Pulley	M30011
43	Threaded Locking Ring	M30012
45	Fixing Pin for Tray	M30013
46	Kold Motor Cover	M28500/KOLD
47	Fork for Kold Electronic	M28122/KOLD
48	Small Mazzer Drip Tray, M / SJ / K / KOLD	TRAY/SM
49	Upper Insulating	M30014
50	Pilot Light, 110V UL, Red	M28258006

54	Kold Belt	M30015
55	Kold Driving Pulley	M30016
56	Backstand	M30018
58	Cooling Fan, Robur/Kold	M30019
62	Two Pole Rotative Switch, On/Off	M28161
63	Knob for M28161 & M28166 Switches	M28166/K
65	Ground Plate	M28902
66	Terminal Blocks	M28903
67	Under Terminal Blocks	M28904
68	Cable Locking HSK-K PG11 Black	M30020
69	Mazzer Foot, Robur/Kold	M28258/R
70	Nut for Cable Locking	M30021
71	Mazzer Power Cable	M30022
72	External Unipotential Clamp, Plate	M28905
74	Mazzer Grounds Tray Clip	M28259
75	Kold Bottom Plate	M30040
76	Lateral Insulating	M30041
77	Kold System Plate	M30042
78	New Style, Relay for Robur / Kold	M28346
79	Capacitor 60 uF	M19058
81	Board for Double Timer	M28700
82	Capacitor 80 uF	M19060
84	Gasket AER Stop	M28400004
85	Grid / Screen Robur/ Kony/Super Jolly / Kold Electronic	M28670
87	Funnel, Robur/Major/Kold	M28660
88	Coffee Outlet Guard	M28250
89	Bottom for Push Button Lid	M28650
90	O - Ring NBR70	M28680
92	Card for Push Button, with Display	M28640
93	Gasket for Push Button Holder Lid	M28630
94	Push Button Holder Lid with Adhesive Display	M28620
95	Wire for Push Button Display	M28640/WIRE
96	Cable Locking 40-80-20 Black	M28600
97	Tamper Holder	M28860